

BOARD SUPPORT PACKAGE

For Connect Tech NVIDIA Jetson Nano Carriers

BSP Version: Nano-32.2.1 V001

Last Updated: 2020/01/09

Introduction

This Board Support Package adds support for Connect Tech Jetson Nano family of carrier boards to Linux4Tegra. It includes any extra files required to use all the features of the carriers. Please check the "Product Specific Details" section for what features for your board is supported with this BSP release and the "Changes" section for the changes made between versions. You can check which version of the BSP you have installed by running: cat /etc/cti/CTI-L4T.version

Check for the Latest Version of the CTI-L4T BSP at:

https://connecttech.com/resource-center/l4t-board-support-packages/

Requirements

Consult KDB344 at for TX2 hardware compatibility with your carrier. https://connecttech.com/resource-center-category/all-kdb-entries/

- o x86 based host machine running Ubuntu 16.04 or Ubuntu 18.04
- o Jetpack 4.2.2 installed via Nvidia SDK Manager (from Nvidia Embedded Download Center)
- o Nano module
- o Connect Tech Nano Family Carrier
- o USB Cable for flashing

*L4T version can be found in /etc/nv_tegra_release and will look like this:

#R32 (release), REVISION: 2.0

Installation

- 1. Before Installing the BSP you will need to install Jetpack 4.2.2 on the x86 host system using the Nvidia SDK Manager
- Copy the CTI-L4T-NANO-32.2.1-V001.tgz package into ~/nvidia/nvidia_sdk/JetPack_4.2.2_Linux_GA_P3448-0020/Linux_for_Tegra/
- 3. Extract the BSP:

tar -xzf CTI-L4T-NANO-32.2.1-V001.tgz

4. Change into the CTI-L4T directory:

cd ./CTI-L4T

5. Run the install script (as root or sudo) to automatically install the BSP files to the correct locations:



sudo ./install.sh cd ..

6. The CTI-L4T BSP is now installed on the host system and it should now be able to flash the Nano.

7. To flash on the Nano use the following (do not add ".conf"):

CTI Assisted Flashing: ./cti-flash.sh

Manual Flash: ./flash.sh cti/nano/photon mmcblk0p1

Flashing Instructions

- 1. Connect the Nano and Carrier to the computer via USB, following the instructions in the appropriate manual
- 2. Put the system to be flashed into recovery mode, following the instructions in the appropriate manual
- 3. Run ./flash.sh <board> mmcblk0p1 from Linux_for_Tegra directory
- 4. Once the flashing has completed, the Nano will reboot
- 5. To switch between different boards, you will need to repeat these steps
- 6. There is currently no run time support for switching profiles on the Nano

Product Specific Details

NGX003

- USB Support
- Camera Support
- Display(HDMI)
- Fan
- SD Card
- NVMe
- PoE
- Wireless Expansion (WiFi/LTE with SIM)

Changes

Version NANO-32.2.1 V001, Jan 09, 2020

• Initial release on Jetpack 4.2.2

Version 300, September 11, 2019

• Initial Release for the Nano



Contact Connect Tech

If you have any problems, questions or suggestions regarding the Board Support Package and hardware, please feel free to contact Connect Tech Inc.

Contact Information	
	Please go to the <u>Connect Tech Resource Center</u> for product manuals, installation guides, device drivers, BSPs and technical tips.
Support	Submit your <u>technical support</u> questions to our support engineers. Technical Support representatives are available Monday through Friday, from 8:30 a.m. to 5:00 p.m. Eastern Standard Time.
Contact Information	support@connecttech.com sales@connecttech.com www.connecttech.com
	Toll Free: 800-426-8979 (North America only) Telephone: +1-519-836-1291 Facsimile: 519-836-4878 (on-line 24 hours)