

BOARD SUPPORT PACKAGE

For Connect Tech NVIDIA® Jetson Orin™ NX/Orin™ Nano Carriers

BSP Version: ORIN-NX-NANO-35.5.0-INTELRS V001
Last Updated: 2024/12/02

1. Introduction

This Board Support Package adds support for the Connect Tech Jetson Orin™ NX and Orin™ Nano family of carrier boards to Linux4Tegra. It includes any extra files required to use all the features of Connect Tech carriers.

Please check Section 3 for supported features for your board and Section 7 for the changes made between versions. You can check which version of the BSP you have installed by running:

```
cat /etc/cti/CTI-L4T.version
```

Check for the Latest Version of the CTI-L4T BSP at:
<https://connecttech.com/resource-center/l4t-board-support-packages/>

2. Requirements

- x86/x64 based host machine running Ubuntu 18.04 or 20.04
- JetPack 5.1.3 / L4T 35.5.0 installed (see Section 4)
- Orin™ NX or Orin™ Nano module
- Connect Tech Orin™ NX/Orin™ Nano Carrier
- USB Cable for flashing

*L4T version can be found in /etc/nv_tegra_release and will look like this:
R35 (release), REVISION: 5.0

3. BSP Features

3.1 Supported Cameras in BSP

- Intel Realsense (D457)

3.2 Product Specific Details

NGX010 (Rudi-NX)

- USB 3.0 Support
- USB OTG Support
- Micro SD Card
- GbE Phy Support
- NVMe Card Support
- Wifi/Bluetooth support
- CAN Support
- UART Support
- I2C Support
- GPIO Support
- SPI Support
- PWM Support
- GMSL Camera Support (Intel Realsense)

NGX018 (Hadron GMSL)

- USB 3.0 Support
- USB OTG Support
- GbE Phy Support
- NVMe Card Support
- Wifi/Bluetooth support
- CAN Support
- UART Support
- I2C Support
- GPIO Support
- PWM Support
- GMSL Camera Support

3.3 Limitations and Known Issues

1. Micro SD card on CTI Xavier™ NX carriers will not work with Orin™ NX or Orin™ Nano As pin mapping for those pins has changed.

4. Installation

4.1 Obtaining NVIDIA® Jetpack

Before Installing the BSP you will need to install JetPack 5.1.3 on the host

system using NVIDIA® SDK Manager (section 4.1.1) or from the NVIDIA® Embedded Download Center (section 4.1.2)

4.1.1 Installing JetPack from SDK Manager

For installing using sdkmanager, please follow installation steps from kdb373 for Jetpack 4.2+ <https://connecttech.com/resource-center/kdb373/>

4.1.2 Installing JetPack from NVIDIA® Embedded Download Center

1. Create a new directory for installing the Jetpack. Referred to as <BSP_ROOT> in these instructions.
2. Go to Jetpack Release Page <https://developer.nvidia.com/embedded/jetson-linux-r3550>
3. Download the "L4T Driver Package (BSP)" and "Sample Root Filesystem" files for Orin modules (t234 platform).

4. Put the "L4T Driver Package (BSP)" and "Sample Root Filesystem" in <BSP_ROOT>. Afterwards, you should have the following files in <BSP_ROOT>

- jetson_linux_r35.5.0_aarch64.tbz2
- tegra_linux_sample-root-filesystem_r35.5.0_aarch64.tbz2

5. Extract the "L4T Driver Package" tarball:

```
cd <BSP_ROOT>
sudo tar -jxf jetson_linux_r35.5.0_aarch64.tbz2
```

6. You should now have a new directory called Linux_for_Tegra in your <BSP_ROOT> folder. Extract the "Sample Root Filesystem" into Linux_for_Tegra/rootfs.

```
sudo tar -C Linux_for_Tegra/rootfs/ -xjf tegra_linux_sample-root-filesystem_r35.5.0_aarch64.tbz2
```

4.2 CTI BSP Installation

1. Copy the CTI-L4T-ORIN-NX-NANO-35.5.0-V###.tgz package into <BSP_ROOT>/Linux_for_Tegra.

If you are using Nvidia's SDK manager then "<BSP_ROOT>" will be:
~/nvidia/nvidia_sdk/<JetPack_Version>_Linux_JETSON_NX_ORIN_TARGETS/
or

~/nvidia/nvidia_sdk/<JetPack_Version>_Linux_JETSON_NANO_ORIN_TARGETS/
depending on your target module.

Otherwise if manually installing from the NVIDIA® Embedded Download Center
<BSP_ROOT> will be the folder created previously

```
cp CTI-L4T-ORIN-NX-NANO-35.5.0-V###.tgz <BSP_ROOT>/Linux_for_Tegra
```

```
2. Extract the BSP: tar -xzf CTI-L4T-ORIN-NX-NANO-35.5.0-V###.tgz  
cd <BSP_ROOT>/Linux_for_Tegra  
sudo tar -xzf CTI-L4T-ORIN-NX-NANO-35.5.0-V###.tgz
```

```
3. Change into the CTI-L4T directory:  
cd <BSP_ROOT>/Linux_for_Tegra/CTI-L4T
```

4. Run the install script (as root or sudo) to automatically install the BSP files
to the correct locations:

```
sudo ./install.sh  
#return to Linux_for_Tegra  
cd ..
```

5. The CTI-L4T BSP is now installed on the host system and it should now be able
to flash the Orin™ NX/Orin™ Nano module.

5. Flashing Orin™ NX/Orin™ Nano Modules

1. Connect an NVMe m.2 card to one of the m.2 slots on your Orin™ NX/Orin™ Nano carrier.

2. Connect the Orin™ NX/Orin™ Nano and Carrier to the computer via USB, following the
instructions in the appropriate manual.

3. Put the system to be flashed into recovery mode, following the
instructions in the appropriate manual

4. There are two options for flashing Jetson modules:

Using CTI's automated script:
sudo ./cti-flash.sh

Follow the menu and select your desired configuration. Once selected,

the device will start to flash.

Using the Manual Method with cti-nvme-flash:

Note do not add the ".conf" file extension to the <config> parameter:

Manual Flash: `sudo ./cti-nvme-flash.sh cti/<module>/<boardname>/<config>`

<module> is either orin-nx or orin-nano depending on your module.

Examples:

```
sudo ./cti-nvme-flash.sh cti/orin-nx/boson/base
```

```
sudo ./cti-nvme-flash.sh cti/orin-nano/boson/base
```

5. Once the flashing has completed, the Orin™ NX/Orin™ Nano will reboot

6. Upgrading to a New Package Release

Upgrading L4T or CTI-BSP versions without reflashing is not currently supported.

7. Switching Profiles on Orin™ NX

1. Open a terminal on the Orin™ NX/Orin™ Nano
2. Run "`sudo cti-orin-nx-nano-fdt.sh`"
3. Select the profile you wish to switch to from the menu.
4. Select the target module (Orin-NX or Orin-NANO) from the menu.
5. Restart the system

Note: This script updates the dtb by appending/replacing the FDT variable in extlinux.conf

8. Change Log

Version ORIN-NX-NANO-35.5.0-INTELR V001, Dec 02, 2024

- Initial release of Rudi-NX (4 CAM) and Hadron-GMSL (2 CAM) with Intel Realsense (D457) for Orin™ NX/Orin™ Nano

Contact Connect Tech

If you have any problems, questions or suggestions regarding the Board Support Package and hardware, please feel free to contact Connect Tech Inc.

Contact Information	
Support	<p>Please go to the Connect Tech Resource Center for product manuals, installation guides, device drivers, BSPs and technical tips.</p> <p>Submit your technical support questions to our support engineers. Technical Support representatives are available Monday through Friday, from 8:30 a.m. to 5:00 p.m. Eastern Standard Time.</p>
Contact Information	<p>support@connecttech.com sales@connecttech.com www.connecttech.com</p> <p>Toll Free: 800-426-8979 (North America only) Telephone: +1-519-836-1291 Facsimile: 519-836-4878 (on-line 24 hours)</p>