

BOARD SUPPORT PACKAGE

For Connect Tech NVIDIA® Jetson XAVIER-NX-AVT Carriers

BSP Version: XAVIER-NX-AVT-35.4.1 V001
Last Updated: 2024/05/17

1. Introduction

This Board Support Package adds support for the Connect Tech Jetson Xavier™ NX family of carrier boards to Linux4Tegra. It includes any extra files required to use all the features of the Connect Tech carriers.

Please check Section 3. For supported features for your board and Section 8 for the changes made between versions. You can check which version of the BSP you have installed by running:

```
cat /etc/cti/CTI-L4T.version
```

Check for the Latest Version of the CTI-L4T BSP at:
<https://connecttech.com/resource-center/l4t-board-support-packages/>

2. Requirements

- x86/x64 based host machine running Ubuntu 18.04 or 20.04
- JetPack 5.1.2 / L4T 35.4.1 installed (see Section 4)
- Xavier™ NX module
- Connect Tech Xavier™ NX Carrier
- USB Cable for flashing

*L4T version can be found in /etc/nv_tegra_release and will look like this:
R35 (release), REVISION: 4.1

3. BSP Features

3.1 Product Specific Details

NGX003 (Photon)

- USB 3.0 Support
- USB OTG Support
- MIPI Camera Support
- HDMI Support
- Micro SD Card Support
- NVMe Card Support
- Wifi/Bluetooth Card Support
- Cellular Card Support
- RGB LED Support
- UART Support
- I2C Support
- GPIO Support

Supported MIPI Cameras:

- Allied Vision Alvium Series Mipi cameras

NGX004 (Quark)

- USB 3.0 Support
- USB OTG Support
- MIPI Camera Support
- Micro SD Card
- GbE Phy Support
- CAN Support
- UART Support
- I2C Support
- GPIO Support
- SPI Support
- PWM Support

Supported MIPI Cameras:

- Allied Vision Alvium Series Mipi cameras

NGX012 (Hadron)

- USB 3.0 Support
- USB OTG Support
- GbE Phy Support
- NVMe Card Support
- Wifi/Bluetooth support
- CAN Support
- UART Support
- I2C Support

- GPIO Support
- SPI Support
- PWM Support
- MIPI camera support

Supported MIPI Cameras:

- Allied Vision Alvium Series Mipi cameras

3.2 Limitations and Known Issues

1. OTA deb package update is currently not supported in this package. Please do not run `apt-get upgrade nvidia-l4t-kernel`, as you can break the OS.
2. Jetpack 5.0+ deploys a rootfs without any bluetooth plugin support. When connecting your tegra module to a device you may find it classified as a generic type. The module will disconnect shortly after connecting, to fix this you need to setup bluetooth support on your tegra device.

It is up to you to research and implement plugins, when you do be sure to modify `/lib/systemd/system/bluetooth.service.d/nv-bluetooth-service.conf`:

remove `--noplugin=audio,a2dp,avrcp` from the line containing:
`ExecStart=/usr/lib/bluetooth/bluetooth -d --noplugin=audio,a2dp,avrcp`

4. Installation

4.1 Obtaining NVIDIA® Jetpack

Before Installing the BSP you will need to install JetPack 5.0.2 on the host system using the NVIDIA® SDK Manager (section 4.1.1) or from the NVIDIA® Embedded Download Center (section 4.1.2)

4.1.1 Installing JetPack from SDK Manager

Please follow installation steps from [kdb373](https://connecttech.com/resource-center/kdb373/) for Jetpack 4.2+ <https://connecttech.com/resource-center/kdb373/>

4.1.2 Installing JetPack from NVIDIA® Embedded Download Center

1. Create a new directory for installing Jetpack. Referred to as <BSP_ROOT> in these instructions
2. Go to Jetpack Release Page <https://developer.nvidia.com/embedded/jetson-linux-r351>
3. Download the "L4T Driver Package (BSP)" and "Sample Root Filesystem" files for Xavier™ NX
4. Put the "L4T Driver Package (BSP)" "Sample Root Filesystem" in <BSP_ROOT>. Afterwards, you should have the following files in <BSP_ROOT>
 - jetson_linux_r35.4.1_aarch64.tbz2
 - tegra_linux_sample-root-filesystem_r35.4.1_aarch64.tbz2
5. Extract the "L4T Driver Package" tarball:

```
cd <BSP_ROOT>
sudo tar -jxf jetson_linux_r35.4.1_aarch64.tbz2
```
6. You should now have a new directory called Linux_for_Tegra in your <BSP_ROOT> folder. Extract the "Sample Root Filesystem" into Linux_for_Tegra/rootfs.

```
sudo tar -C Linux_for_Tegra/rootfs/ -xjf tegra_linux_sample-root-filesystem_r35.4.1_aarch64.tbz2
```

4.2 CTI BSP Installation

1. Copy the CTI-L4T-XAVIER-NX-AVT-35.4.1-V####.tgz package into <BSP_ROOT>/Linux_for_Tegra.

If using Nvidia's SDK manager then "<BSP_ROOT>" will be:
~/nvidia/nvidia_sdk/<JetPack_Version>_Linux_JETSON_XAVIER_NX_TARGETS/

Otherwise if manually installing from NVIDIA® Embedded Download Center <BSP_ROOT> will be the folder created previously

```
cp CTI-L4T-XAVIER-NX-AVT-35.4.1-V####.tgz <BSP_ROOT>/Linux_for_Tegra
```

2. Extract the BSP: tar -xzf CTI-L4T-XAVIER-NX-AVT-35.4.1-V####.tgz

```
cd <BSP_ROOT>/Linux_for_Tegra
sudo tar -xzf CTI-L4T-XAVIER-NX-AVT-35.4.1-V####.tgz
```

3. Change into the CTI-L4T directory:

```
cd <BSP_ROOT>/Linux_for_Tegra/CTI-L4T
```

4. Run the install script (as root or sudo) to automatically install the BSP files

to the correct locations:

```
sudo ./install.sh
#return to Linux_for_Tegra
cd ..
```

5. The CTI-L4T BSP is now installed on the host system and it should now be able to flash the Xavier™ NX module.

5. Flashing Xavier™ NX Modules

1. Connect the Xavier™ NX and Carrier to the computer via USB, following the instructions in the appropriate manual.

2. Put the system to be flashed into recovery mode, following the instructions in the appropriate manual

3. To flash on the Xavier™ NX use the following (do not add ".conf" in <config>):

Manual Flash: `./flash.sh cti/<module>/<boardname>/<config> mmcblk0p1`

<module> is xavier-nx for all xavier-nx modules

Example:

```
./flash.sh cti/xavier-nx/photon/base mmcblk0p1
```

4. Once the flashing has completed, the Xavier™ NX will reboot

6. Upgrading to a New Package Release

Upgrading L4T or CTI-BSP versions without reflashing is not currently supported.

7. Switching Profiles on Xavier™ NX

1. Open a terminal on the Xavier™ NX

2. Run "sudo cti-nx-fdt.sh"

3. Select the profile you wish to switch to from the menu

4. Restart the system

Note: This script updates the dtb by appending/replacing the FDT variable in extlinux.conf

8. Change Log

Version NX-AVT-35.4.1 V001, May 17, 2024

- Initial Release for Allied Vision Xavier™ NX Carriers on I4t 35.4.1.
- Includes Hadron, Photon and Quark configs.

Contact Connect Tech

If you have any problems, questions or suggestions regarding the Board Support Package and hardware, please feel free to contact Connect Tech Inc.

Contact Information	
Support	<p>Please go to the Connect Tech Resource Center for product manuals, installation guides, device drivers, BSPs and technical tips.</p> <p>Submit your technical support questions to our support engineers. Technical Support representatives are available Monday through Friday, from 8:30 a.m. to 5:00 p.m. Eastern Standard Time.</p>
Contact Information	<p>support@connecttech.com sales@connecttech.com www.connecttech.com</p> <p>Toll Free: 800-426-8979 (North America only) Telephone: +1-519-836-1291 Facsimile: 519-836-4878 (on-line 24 hours)</p>