

# **BOARD SUPPORT PACKAGE**

# For Connect Tech NVIDIA Jetson AGX Xavier Carriers

BSP Version: AGX-32.4.2 V002

Last Updated: 2020/06/15

## Introduction

This Board Support Package adds support for Connect Tech Jetson AGX Xavier family of carrier boards to Linux4Tegra. It includes any extra files required to use all the features of the carriers. Please check the "Product Specific Details" section for what features for your board is supported with this BSP release and the "Changes" section for the changes made between versions. You can check which version of the BSP you have installed by running: cat /etc/cti/CTI-L4T.version

Check for the Latest Version of the CTI-L4T BSP at:

https://connecttech.com/resource-center/l4t-board-support-packages/

# Requirements

- o x86 based host machine running Ubuntu 18.04
- o JetPack 4.3 installed (from NVIDIA Embedded Download Center)
- o AGX Xavier module
- Connect Tech AGX Xavier Carrier
- USB Cable for flashing
- o L4T 32.3.1

#R32 (release), REVISION: 1.0

#### Installation

- 1. Before Installing the BSP you will need to install JetPack on the x86 host system using the NVIDIA SDK manager.
- 2. After successfull installation of Jetpack,copy the CTI-L4T-AGX-32.4.2-V002.tgz package from "install" directory into "Linux\_for\_Tegra".

```
Ex. Typical path for "Linux_for_Tegra" directory: 
~/nvidia/nvidia_sdk/JetPack_4.2_Linux_P2888/Linux_for_Tegra/
```

3. Extract the BSP:

```
tar -xzf CTI-L4T-AGX-32.4.2-V002.tgz
```

4. Extract rootfs to Linux\_for\_Tegra directory tar -zxvf rootfs.tgz

<sup>\*</sup>L4T version can be found in /etc/nv\_tegra\_release and will look like this:



5. Change into the CTI-L4T directory: cd ./CTI-L4T

- 6. Run the install script (as root or sudo) to automatically install the BSP files to the correct locations: sudo ./install.sh cd ..
- 7. The CTI-L4T BSP is now installed on the host system and it should now be able to flash the Xavier module.
- 8. To flash on the Xavier use the following (do not add ".conf"):

CTI Assisted Flashing: ./cti-flash.sh

Manual Flash: ./flash.sh <boardname> mmcblk0p1 Examples: ./flash.sh rogue agx103 mmcblk0p1

Note: Make sure that the \*.conf file is present in the path where flash.sh resides.

# Flashing Instructions

- 1. Connect the Xavier and Carrier to the computer via USB, following the instructions in the appropriate manual.
- 2. Put the system to be flashed into recovery mode, following the instructions in the appropriate manual
- 3. Run ./flash.sh <board> mmcblk0p1 from Linux\_for\_Tegra directory
- 4. Once the flashing has completed, the Xavier will reboot
- 5. To switch between different boards, you will need to repeat these steps. There is currently no run time support for switching profiles on the AGX Xavier

# **Product Specific Details**

## AGX101 (Rogue)

- o CAN Support
- USB Support
- o GbE Phy Support
- o 2 IM
- o Supports JCB002 adapter with 8 cameras (Only for Xavier)
- o SUPPORTS XAVIER 8GB MODULE
  - o SPI support

NOTE: Due to HW Limitations There is NO CAN on ENG Samples

# AGX103 (RogueX)

o CAN Support



- o USB Support
- o PCle Support
  - NVMe Support
- o I2C-GPIO PCA9531 Support
  - GPIO pin @0x60: 4,5,6,7
  - GPIO pin @0x61: 12,13,14,15
- o GbE Phy Support
- o 2 IM
  - Supports JCB002 adapter with 8 cameras (Only for Xavier)
- o SUPPORTS XAVIER 8GB MODULE
  - SPI support

NOTE: Due to HW Limitations There is NO CAN on ENG Samples

# AGX001 (Mimic)

- o CAN Support
- o USB Support
- o PCle Support
- o GbE Phy Support

NOTE: Currently NO CSI camera support

NOTE: Currently NO SPI support

# GMSL Camera Platform for AGX Xavier Dev kit (JCB004)

o Supports JCB004 adapter on dev kit for 8 cameras (e-Con and IMX390)

# Changes

Version AGX-32.4.2 V002, June 15, 2020

- o Added support for JCB004 IMX390 and E-Con cameras on dev kit
- o Added support for JCB002 E-Con camera on rogue/rogueX
- o Added support for Elroy, Spacely on Mimic

Version AGX-32.4.2 V001, June 05, 2020

o Initial release

Version AGX-32.3.1 V006, May 29, 2020

- o Fixed login loop
- o Added deb packaged

Version AGX-32.3.1 V004, May 07, 2020

o Fixed issue with install.sh script

Version AGX-32.3.1 V004, Feb 24, 2020

o Added support for Leopard IMX390 cameras on JCB004 for Xavier devkit

Version AGX-32.3.1 V003, Feb 14, 2020

o Added support for E-CON AR0330 cameras on JCB004 for Xavier devkit



#### Version AGX-32.3.1 V002, Feb 13, 2020

o Added support for E-CON AR0330 cameras on JCB002 for Rogue and RogueX

#### Version AGX-32.3.1 V001, Feb 06, 2020

- o Initial version for Jetpack 4.3 (L4T 32.3.1)
- o Added JCB002 adapter support to RogueX
- o Fixed eth0 hotplug issue
- o Prevented i2c error message from appearing in dmesg logs of modules with no camera support
- o Added SPI support

#### Version AGX-32.2.1 V003, Dec 23, 2019

- o Fixed cti-flash.sh to support flashing
- o Corrected verbose in install.sh

## Version AGX-32.2.1 V002, Dec 10, 2019

o Support for Xavier 8GB module for Rogue and Rogue X carriers

# Version AGX-32.2.1, Dec 05, 2019

o Initial Release for Jetpack 4.2.2 (L4T 32.2.1)

#### Version AGX-32.1.0, Nov 08, 2019

o Added camera support (MIPI CSI Expansion)

#### Version AGX-32.1.0, Nov 04, 2019

o Initial Release

## Version 203, Jun 17, 2019

- o Added Rogue Camera Support
- o Fixed an Issue Where Some Modules Would Not Flash

## Version 202, Apr 30, 2019

o Changed Kernel Name to 4.9.104-tegra

## Version 201, Apr 8, 2019

o Initial Release for the Mimic and Rogue Jetpack 4.2 (L4T 32.1.0)

# Version 200, Mar 15, 2019

o Initial Release for the Mimic and Rogue Jetpack 4.1 (L4T 31.1.0)

## **Contact Connect Tech**

If you have any problems, questions or suggestions regarding the Board Support Package and hardware, please feel free to contact Connect Tech Inc.

Contact Information		
Support	Please go to the Connect Tech Resource Center for product manuals,	
	installation guides, device drivers, BSPs and technical tips.	



	Technical Sup	Submit your <u>technical support</u> questions to our support engineers. Technical Support representatives are available Monday through Friday, from 8:30 a.m. to 5:00 p.m. Eastern Standard Time.		
Contact Information	support@connecttech.com sales@connecttech.com www.connecttech.com			
	Toll Free: Telephone: Facsimile:	800-426-8979 (North America only) +1-519-836-1291 519-836-4878 (on-line 24 hours)		