

# BOARD SUPPORT PACKAGE

# For Connect Tech NVIDIA Jetson AGX Carriers

BSP Version: AGX-AVT-32.7.2 V003

Last Updated: 2022/10/04

#### Introduction

This Board Support Package adds support for Connect Tech Jetson AGX Xavier family of carrier boards to Linux4Tegra. It includes any extra files required to use all the features of the carriers. Please check the "Product Specific Details" section for what features for your board is supported with this BSP release and the "Changes" section for the changes made between versions. You can check which version of the BSP you have installed by running: cat /etc/cti/CTI-L4T.version

Check for the Latest Version of the CTI-L4T BSP at: https://connecttech.com/resource-center/l4t-board-support-packages/

## Supported Cameras in BSP

• Allied Vision Alvium 1500 C and 1800 C sensors

### Requirements

- x86 based host machine running Ubuntu 18.04
- JetPack 4.6.2 installed (from NVIDIA Embedded Download Center)
- AGX Xavier module
- Connect Tech AGX Xavier Carrier
- USB Cable for flashing
- L4T 32.7.2

\*L4T version can be found in /etc/nv\_tegra\_release and will look like this: # R32 (release), REVISION: 7.2

### Installation

1. Before Installing the BSP you will need to install JetPack 4.6.2 on the x86 host system using the NVIDIA SDK Manager or from the source packages on NVIDIA's website as detailed below.



- 2. Copy the CTI-L4T-AGX-AVT-32.7.2-V###.tgz package into ~/nvidia/nvidia\_sdk/JetPack\_4.6.2\_Linux\_JETSON\_AGX\_XAVIER/Linux\_for\_Tegra/
- 3. Extract the BSP: tar -xzf CTI-L4T-AGX-AVT-32.7.2-V###.tgz
- 4. Change into the CTI-L4T directory: cd ./CTI-L4T
- 5. Run the install script (as root or sudo) to automatically install the BSP files to the correct locations:

sudo ./install.sh cd ..

- 6. The CTI-L4T BSP is now installed on the host system and it should now be able to flash the AGX Xavier module.
- 7. To flash on the AGX Xavier use the following (do not add ".conf"):

CTI Assisted Flashing: ./cti-flash.sh

Manual Flash: ./flash.sh cti/<module>/<boardname>/<config> mmcblk0p1

#### Examples:

./flash.sh cti/xavier/rogueX/base mmcblk0p1 ./flash.sh cti/xavier-l/rogue/li-imx274 mmcblk0p1

# Installing JetPack from SDK Manager

Please follow installation steps from kdb374 for Jetpack 4.2+ https://connecttech.com/resource-center/kdb374/

# Installing JetPack from Nvidia's Source packages (Alternate approach)

- 1. Go to https://developer.nvidia.com/embedded/linux-tegra-archive and click on the green button labeled "32.7.2 >".
- 2. Download the "L4T Driver Package (BSP)" and "Sample Root Filesystem" files for AGX Xavier. Afterwards, you should have the files "Jetson\_Linux\_R32.7.2\_aarch64.tbz2" and "Tegra\_Linux\_Sample-Root-Filesystem\_R32.7.2\_aarch64.tbz2".



- 3. Create a directory named ~/nvidia/nvidia\_sdk/JetPack\_4.6.2\_Linux\_JETSON\_AGX\_XAVIER/ and copy the "Jetson\_Linux\_R32.7.2\_aarch64.tbz2" file you downloaded into that directory.
- 4. Unzip the tarball:

"sudo tar jxf Jetson Linux R32.7.2 aarch64.tbz2"

5. You should now have a new directory called Linux\_for\_Tegra in your "JetPack\_4.6.2\_Linux\_JETSON\_AGX\_XAVIER" folder. Change directories into that and then copy the "Tegra\_Linux\_Sample-Root-Filesystem\_R32.7.2\_aarch64.tbz2" file you downloaded into the rootfs folder inside.

6. Change into the rootfs folder and unzip the tarball:

"sudo tar jxf Tegra Linux Sample-Root-Filesystem R32.7.2 aarch64.tbz2"

7. If you wish to flash one of NVIDIA's devkits, or move on to installing CTI's BSP. You can change directories

back to ~/nvidia/nvidia\_sdk/JetPack\_4.6.2\_Linux\_JETSON\_AGX\_XAVIER/Linux\_for\_Tegra/ and run: "sudo ./apply\_binaries.sh"

# Flashing AGX Xavier Modules

- 1. Connect the AGX Xavier and Carrier to the computer via USB, following the instructions in the appropriate manual.
- 2. Put the system to be flashed into recovery mode, following the instructions in the appropriate manual
- 3. Run "./cti-flash.sh" or "./flash.sh cti/<module>/<board>/<config> mmcblk0p1" from Linux\_for\_Tegra directory
- 4. Once the flashing has completed, the Xavier will reboot
- 5. To switch between different boards, you can repeat these steps. Alternatively follow the instructions below for runtime switching profiles on the Xavier

# Switching Profiles on Xavier

- 1. Open a terminal on the Xavier
- 2. Run "sudo cti-agx-fdt.sh"



- 3. Select the profile you wish to switch to from the menu
- 4. Restart the system

Note: This script updates dtb by appending/replacing the FDT variable in extlinux.conf It also sets root=/dev/mmcblk0p1 by modifying the "APPEND" variable

# Upgrading to a New Package Release

Note that using sudo apt-get upgrade may break dependencies required by the Nvidia Jetpack.

It is recommended you reflash your module if you wish to update to a newer package version.

Deb Packages are still provided on the CTI deb server, and our source list is still provided in the release. If you wish to use apt-get upgrade, you can do so at your own risk:

run:

apt-get update apt-get upgrade nvidia-l4t-core

Note that you will need to use the device tree switching script described in the previous section to reselect your configuration.

This will ensure that you are using the updated device tree.

# **Product Specific Details**

### AGX101 (Rogue)

- CAN Support
- USB 3.1 Support
- USB OTG Support
- GbE Phy Support
- Supports JCB005 Allied Vision Camera(4-Cam and 6-Cam).
- SPI support
- UART support
- I2C support
- GPIO support
- NVMe card support
- Wifi/Bluetooth card support
- Micro SD card support



• HDMI support

### AGX103 (RogueX)

- CAN Support
- USB 3.1 Support
- USB OTG Support
- Wifi/Bluetooth card Support
- NVMe card support
- I2C Support
- GPIO Support
- GbE Phy Support
- Supports JCB005 Allied Vision Camera(4-Cam and 6-Cam).
- SPI support
- UART support
- HDMI support
- Micro SD Card support.

### AGX105 (Rogue-10G)

- CAN Support
- USB 3.1 Support
- USB OTG Support
- Wifi/Bluetooth card Support
- NVMe card support
- OCuLink connector
- I2C Support
- GPIO Support
- GbE Phy Support
- 10G GbE Phy Support
- Supports JCB005 Allied Vision Camera(4-Cam and 6-Cam).
- SPI support
- UART support
- HDMI support
- Micro SD Card support.

# Changes

Version AGX-AVT-32.7.2 V004, Oct 03, 2022

- Added support for AGX115.
- Updated Allied Vision drivers to release tag l4t-32.7.1-4.0.0.



#### Version AGX-AVT-32.7.2 V002, Aug 26, 2022

• Added support for PTN5150 USB CC Logic chip to AGX113.

#### Version AGX-AVT-32.7.2 V001, June 20, 2022

• Initial release on Jetpack 4.6.2 L4T 32.7.2.

#### Version AGX-AVT-32.7.1 V001, May 09, 2022

• Initial release on Jetpack 4.6.1 L4T 32.7.1.

#### Version AGX-AVT-32.6.1 V003, February 11, 2022

- o Updated allied version kernel drivers to version 2.1.0.
- o Fixes kernel module version errors experienced with newer avc camera firmware.

#### Version AGX-AVT-32.6.1 V002, Aug 26, 2021

- Adds updates addressed in Nvidia's June 18th security bulletin
- Adds Allied Vision cameras support for RogueX
- Initial release on Jetpack 4.6 L4T 32.6.1.
- Note: This package does not support other camera sensors.

#### Version AGX-AVT-32.5.2 V001, July 21, 2021

- Initial release on Jetpack 4.5.2 L4T 32.5.2.
  - o (Note) at the time of release (2021-07-21), Jetpack 4.5.2 is not supported by sdkmanager,

sources also need to be manually downloaded (source sync.sh does not work for 32.5.2 tag).

- o Supports Allied Vision Camera on JCB005 adapter board on AGX101(Rogue).
- o Uses GPIO35 as reset pin to enable external camera GPIOs on JCB005.
- o Note: This package does not support other camera sensors.

#### Version AGX-AVT-32.5 V005, May 20, 2021

- Supports Allied Vision Camera on JCB005 adapter board on AGX101(Rogue).
- Uses GPIO35 as reset pin to enable external camera GPIOs on JCB005.
- Note: This package does not support other camera sensors.

#### Version AGX-AVT-32.5 V002, Mar 18, 2021

- Supports Allied Vision Camera on JCB005 adapter board on AGX101(Rogue).
- Supports 4-Camera and 6-Camera profiles.
- Note: This package does not support other camera sensors.

#### Version AGX-32.5 V001, Feb 05, 2021

- Initial release on Jetpack 4.5 L4T 32.5
- IMX390 cameras not supported
- Bootloader OTA upgrades are supported.



#### Version AGX-32.4.4 V004, Jan 14, 2021

- Supports IMX274 MIPI camera on Leopard 6 camera adapter board on AGX101(Rogue) and AGX103 (RogueX).
- Supports up to 6 Cameras.
- Note: This package does not support other camera sensors or adaptor boards.

### Version AGX-32.4.4 V003, Dec 09, 2020

• Resolves "disagrees about module\_layout" issue for loading external kernel modules

### Version AGX-32.4.4 V002, Dec 07, 2020

- Supports Allied Vision Camera on JCB005 adapter board on AGX101(Rogue).
- Supports 4-Camera and 6-Camera profiles.
- Note: This package does not support other camera sensors.

#### Version AGX-32.4.4 V001, Nov 13, 2020

• Initial release on Jetpack 4.4.1 L4T 32.4.4

#### Version AGX-32.4.3 V002, October 15, 2020

- Added colour patch from Leopard for IMX390 camera
  - o This supports single camera
- Upgrade support from cti debian server from this version onwards
- Supports apt-get upgrade
- Installs a script to modify extlinux.conf to switch dtb
- Script: cti-agx-fdt.sh
- Install path: /usr/bin
- Execute: sudo cti-agx-fdt.sh
  - o Recommends to perform power cycle when switching between camera profiles using extlinux.conf(cti-agx-fdt.sh)
  - o Set power mode as "MAXN" when running all 8 cameras to avoid any lag.

### Version AGX-32.4.3 V001, July 29, 2020

• Initial release on Jetpack 4.4 L4T 32.4.3

#### Version AGX-32.4.2 V002, June 15, 2020

- Added support for JCB004 IMX390 and E-Con cameras on dev kit
- Added support for JCB002 E-Con camera on rogue/rogueX
- Added support for Elroy, Spacely on Mimic

#### Version AGX-32.4.2 V001, June 05, 2020

• Initial release

#### Version AGX-32.3.1 V006, May 29, 2020

- Fixed login loop
- Added deb packaged

Version AGX-32.3.1 V004, May 07, 2020



• Fixed issue with install.sh script

#### Version AGX-32.3.1 V004, Feb 24, 2020

Added support for Leopard IMX390 cameras on JCB004 for AGX Xavier devkit

#### Version AGX-32.3.1 V003, Feb 14, 2020

Added support for E-CON AR0330 cameras on JCB004 for AGX Xavier devkit

#### Version AGX-32.3.1 V002, Feb 13, 2020

Added support for E-CON AR0330 cameras on JCB002 for Rogue and Rogue-X

#### Version AGX-32.3.1 V001, Feb 06, 2020

- Initial version for JetPack 4.3 (L4T 32.3.1)
- Added JCB002 adapter support to Rogue-X
- Fixed eth0 hotplug issue
- Prevented i2c error message from appearing in dmesg logs of modules with no camera support
- Added SPI support

#### Version AGX-32.2.1 V003, Dec 23, 2019

- Fixed cti-flash.sh to support flashing
- Corrected verbose in install.sh

#### Version AGX-32.2.1 V002, Dec 10, 2019

• Support for AGX Xavier 8GB module for Rogue and Rogue-X carriers

#### Version AGX-32.2.1, Dec 05, 2019

• Initial Release for JetPack 4.2.2 (L4T 32.2.1)

#### Version AGX-32.1.0, Nov 08, 2019

• Added camera support (MIPI CSI Expansion)

### Version AGX-32.1.0, Nov 04, 2019

• Initial Release

#### Version 203, Jun 17, 2019

- Added Rogue Camera Support
- Fixed an Issue Where Some Modules Would Not Flash

#### Version 202, Apr 30, 2019

• Changed Kernel Name to 4.9.104-tegra

#### Version 201, Apr 8, 2019

• Initial Release for the Mimic and Rogue JetPack 4.2 (L4T 32.1.0)

#### Version 200, Mar 15, 2019

• Initial Release for the Mimic and Rogue JetPack 4.1 (L4T 31.1.0)



# **Contact Connect Tech**

If you have any problems, questions or suggestions regarding the Board Support Package and hardware, please feel free to contact Connect Tech Inc.

Contact Information		
Support	Please go to the <u>Connect Tech Resource Center</u> for product manuals, installation guides, device drivers, BSPs and technical tips.	
	Submit your <u>technical support</u> questions to our support engineers. Technical Support representatives are available Monday through Friday, from 8:30 a.m. to 5:00 p.m. Eastern Standard Time.	
Contact Information	support@connecttech.com sales@connecttech.com www.connecttech.com	
	Toll Free: Telephone: Facsimile:	800-426-8979 (North America only) +1-519-836-1291 519-836-4878 (on-line 24 hours)