

BOARD SUPPORT PACKAGE

For Connect Tech NVIDIA Jetson AGX-AVT Carriers

| | |
|---------------|---------------------|
| BSP Version: | AGX-AVT-35.1.0 V003 |
| Last Updated: | 2023/02/01 |

1. Introduction

This Board Support Package adds support for Connect Tech Jetson AGX Xavier family of carrier boards to Linux4Tegra. It includes any extra files required to use all the features of Connect Tech carriers.

Please check Section 3. For supported features for your board and Section 7 for the changes made between versions. You can check which version of the BSP you have installed by running:

```
cat /etc/cti/CTI-L4T.version
```

Check for the Latest Version of the CTI-L4T BSP at:
<https://connecttech.com/resource-center/l4t-board-support-packages/>

2. Requirements

- x86/x64 based host machine running Ubuntu 18.04 or 20.04
- JetPack 5.0.2 / L4T 35.1.0 installed (see Section 4)
- AGX Xavier module
- Connect Tech AGX Xavier Carrier
- USB Cable for flashing

*L4T version can be found in /etc/nv_tegra_release and will look like this:
R35 (release), REVISION: 1.0

3. BSP Features

3.1 Product Specific Details

AGX101 (Rogue)

- CAN Support
- USB 3.1 Support
- USB OTG Support
- GbE Phy Support
- SPI support
- UART support
- I2C support
- GPIO support
- NVMe card support
- Wifi/Bluetooth card support
- Micro SD card support
- HDMI support
- Alvim 1500c and 1800c camera support on JCB005
- Alvim 1500c and 1800c camera support on JCB006

AGX103 (RogueX)

- CAN Support
- USB 3.1 Support
- USB OTG Support
- Wifi/Bluetooth card Support
- NVMe card support
- I2C Support
- GPIO Support
- GbE Phy Support
- SPI support
- UART support
- HDMI support
- Micro SD Card support.
- Alvim 1500c and 1800c camera support on JCB005
- Alvim 1500c and 1800c camera support on JCB006

AGX105 (Rogue-10G)

- CAN Support
- USB 3.1 Support
- USB OTG Support
- Wifi/Bluetooth card Support
- NVMe card support
- OCuLink connector
- I2C Support
- GPIO Support
- GbE Phy Support
- 10G GbE Phy Support

- SPI support
- UART support
- HDMI support
- Micro SD Card support.
- Alviu 1500c and 1800c camera support on JCB005
- Alviu 1500c and 1800c camera support on JCB006

3.3 Limitations and Known Issues

1. Nvme performance in Jetpack 5.0.2 is about half of what it was in previous l4ts.
2. OTA deb package update is currently not supported in this package. Please do not run apt-get upgrade nvidia-l4t-kernel, as you can break the OS.
3. This package does not support any cameras. This is due to the large jump from kernel 4.9 to 5.10, requiring new driver sources from our vendors. Requests for new sources are pending.
4. During development, we ran into many issues that had to be patched in Jetpack 5.0.2 (l4t 35.1.0). There could be bugs in Nvidia's drivers that we have yet to discover. If you need a reliable BSP with plenty of driver and camera support use Jetpack 4.6.2 (l4t 32.7.2) or wait for Jetpack further releases.

4. Installation

4.1 Obtaining Nvidia Jetpack

Before Installing the BSP you will need to install JetPack 5.0.2 on the host system using the NVIDIA SDK Manager (section 4.1.1) or from the Nvidia Embedded Download Center (section 4.1.2)

4.1.1 Installing JetPack from SDK Manager

Please follow installation steps from kdb374 for Jetpack 4.2+ <https://connecttech.com/resource-center/kdb374/>

4.1.2 Installing JetPack from Nvidia Embedded Download Center

1. Create a new directory for installing Jetpack. Referred to as <BSP_ROOT>

in these instructions

2. Go to Jetpack Release Page <https://developer.nvidia.com/embedded/jetson-linux-r351>

3. Download the "L4T Driver Package (BSP)" and "Sample Root Filesystem" files for AGX Xavier.

4. Put the "L4T Driver Package (BSP)" "Sample Root Filesystem" in <BSP_ROOT>. Afterwards, you should have the following files in <BSP_ROOT>

- jetson_linux_r35.1.0_aarch64.tbz2
- tegra_linux_sample-root-filesystem_r35.1.0_aarch64.tbz2

5. Extract the "L4T Driver Package" tarball:

```
cd <BSP_ROOT>
sudo tar -jxf jetson_linux_r35.1.0_aarch64.tbz2
```

6. You should now have a new directory called Linux_for_Tegra in your <BSP_ROOT> folder. Extract the "Sample Root Filesystem" into Linux_for_Tegra/rootfs.

```
sudo tar -C Linux_for_Tegra/rootfs/ -xjf tegra_linux_sample-root-filesystem_r35.1.0_aarch64.tbz2
```

4.2 CTI BSP Installation

1. Copy the CTI-L4T-AGX-AVT-35.1.0-V###.tgz package into <BSP_ROOT>/Linux_for_Tegra.

If using Nvidia's SDK manager then "<BSP_ROOT>" will be:

```
~/nvidia/nvidia_sdk/<JetPack_Version>_Linux_JETSON_AGX_XAVIER_TARGETS/
```

Otherwise if manually installing from Nvidia Embedded Download Center <BSP_ROOT> will be the folder created previously

```
cp CTI-L4T-AGX-AVT-35.1.0-V###.tgz <BSP_ROOT>/Linux_for_Tegra
```

2. Extract the BSP: tar -xzf CTI-L4T-AGX-AVT-35.1.0-V###.tgz
cd <BSP_ROOT>/Linux_for_Tegra
sudo tar -xzf CTI-L4T-AGX-AVT-35.1.0-V###.tgz

3. Change into the CTI-L4T directory:

```
cd <BSP_ROOT>/Linux_for_Tegra/CTI-L4Ti
```

4. Run the install script (as root or sudo) to automatically install the BSP files to the correct locations:

```
sudo ./install.sh
#return to Linux_for_Tegra
cd ..
```

5. The CTI-L4T BSP is now installed on the host system and it should now be able to flash the AGX Xavier module.

5. Flashing AGX Xavier Modules

1. Connect the AGX Xavier and Carrier to the computer via USB, following the instructions in the appropriate manual.

2. Put the system to be flashed into recovery mode, following the instructions in the appropriate manual

3. To flash on the AGX Xavier use the following (do not add ".conf" in <config>):

Manual Flash: `./flash.sh cti/<module>/<boardname>/<config> mmcblk0p1`

<module> is xavier for all xavier modules

Example:

`./flash.sh cti/xavier/rogue/base mmcblk0p1`

4. Once the flashing has completed, the Xavier will reboot

6. Upgrading to a New Package Release

Upgrading L4T or CTI-BSP versions without reflashing is not currently supported.

Support for upgrades via apt and OTA packages will be added in the future

7. Switching Profiles on Xavier

1. Open a terminal on the Xavier

2. Run `"sudo cti-agx-avt-fdt.sh"`

3. Select the profile you wish to switch to from the menu

4. Restart the system

Note: This script updates dtb by appending/replacing the FDT variable in extlinux.conf. It also sets `root=/dev/mmcblk0p1` by modifying the "APPEND" variable

8. Change Log

Version AGX-AVT-35.1.0 V003, Feb 01, 2023

- Added changes to GPIO settings for JCB006 rev c's new GPIO layout

Version AGX-AVT-35.1.0 V002, Jan 17, 2023

- Added support for Allied vision cameras on JCB006 for Rogue

Version AGX-AVT-35.1.0 V001, Dec 21, 2022

- Adding support for Allied vision cameras for Rogue, Rogue10g and RogueX
- NOTE: No other cameras are supported on this BSP release

Version AGX-35.1.0 V001, Oct 7, 2022

- Initial Release for AGX Carriers.

Contact Connect Tech

If you have any problems, questions or suggestions regarding the Board Support Package and hardware, please feel free to contact Connect Tech Inc.

| Contact Information | |
|---------------------|--|
| Support | <p>Please go to the Connect Tech Resource Center for product manuals, installation guides, device drivers, BSPs and technical tips.</p> <p>Submit your technical support questions to our support engineers. Technical Support representatives are available Monday through Friday, from 8:30 a.m. to 5:00 p.m. Eastern Standard Time.</p> |
| Contact Information | <p>support@connecttech.com sales@connecttech.com www.connecttech.com</p> <p>Toll Free: 800-426-8979 (North America only) Telephone: +1-519-836-1291 Facsimile: 519-836-4878 (on-line 24 hours)</p> |