

BOARD SUPPORT PACKAGE

For Connect Tech NVIDIA[®] Jetson Orin[™] NX/Orin[™] Nano Carriers

BSP Version: Last Updated: ORIN-NX-NANO-35.4.1 V008 2024/04/17

1. Introduction

This Board Support Package adds support for the Connect Tech Jetson Orin[™] NX and Orin[™] Nano family of carrier boards to Linux4Tegra. It includes any extra files required to use all the features of Connect Tech carriers.

Please check Section 3 for supported features for your board and Section 9 for the changes made between versions. You can check which version of the BSP you have installed by running:

cat /etc/cti/CTI-L4T.version

Check for the Latest Version of the CTI-L4T BSP at: https://connecttech.com/resource-center/l4t-board-support-packages/

2. Requirements

- x86/x64 based host machine running Ubuntu 18.04 or 20.04
- JetPack 5.1.2 / L4T 35.4.1 installed (see Section 4)
- Orin[™] NX or Orin[™] Nano module
- Connect Tech Orin[™] NX/Orin[™] Nano Carrier
- USB Cable for flashing

*L4T version can be found in /etc/nv_tegra_release and will look like this: # R35 (release), REVISION: 4.1

3. BSP Features

3.1 Product Specific Details



NGX003 (Photon)

- USB 3.0 Support
- USB OTG Supported in device mode.
- HDMI Support
- Micro SD Card Not Supported on Orin[™] NX/Orin[™] Nano
- NVMe Card Support
- PoE Support
- Wifi/Bluetooth Card Not Supported on Orin[™] NX/Orin[™] Nano
 - o NVMe/Wifi-bluetooth mux switch must always be on NVMe

Since device flashes onto NVMe!

- Cellular Card Support
- RGB LED Support
- UART Support
- I2C Support
- GPIO Support
- Tachometer read through driver currently Not Supported.
- MIPI camera support

Supported Mipi Cameras:

- Raspberry Pi IMX219
- ArduCAM IMX477
- Econ E-CAM80 (IMX415)

NGX007 (Boson)

- USB 3.0 Support
- USB OTG Support
- Display(HDMI)
- Micro SD Card Not Supported on Orin[™] NX/Orin[™] Nano
- GbE Phy Support
- CAN Support
- UART Support
- SPI Support
- I2C Support
- PWM Support
- Wifi/Bluetooth Support
- NVMe Card Support
- Framos Camera support
 - Note that CAM4 is disabled as CSI4 is unsupported on Orin[™] NX/Orin[™] Nano

Supported Framos Cameras:

- FSM-IMX290
- FSM-IMX296
- FSM-IMX412
- FSM-IMX415



- FSM-IMX464
- FSM-IMX565
- FSM-IMX568
- FSM-IMX585
- FSM-IMX678

NGX010 (Rudi-NX)

- USB 3.0 Support
- USB OTG Support
- HDMI Support
- NVMe Card Support
- CAN Support
- GbE Phy Support
- Cellular Card Support
- Wifi/Bluetooth card Support
- UART Support
- RS485 Support
- I2C Support
- GPIO Support
- SPI Support
- PWM Support
- RTC Battery Support

(No Camera Configs in Current BSP)

NGX012 (Hadron)

- USB 3.0 Support
- USB OTG Support
- GbE Phy Support
- NVMe Card Support
- Wifi/Bluetooth support
- CAN Support
- UART Support
- I2C Support
- GPIO Support
- SPI Support
- PWM Support
- MIPI camera support

Supported MIPI Cameras:

- ArduCAM IMX477
- Raspberry PI IMX219
- Framos FSM-IMX678 (with FPA-A/P22-v2a adapter)



NGX015 (Polaris)

- USB 3.0 Support
- USB OTG Support
- GbE Phy Support
- NVMe Card Support
- Wifi/Bluetooth support
- CAN Support
- M12 GBE sensor support
- M.2 B-Key modem support
- Wake on LAN Support
- Wake on gpio expander support
- 2x fan and tach support
- Pressure/Temp sensor support
- BMS Support (for reading battery voltage)
- M12 Isolated I/O support
- GMSL Camera Support

Supported GMSL Cameras:

- Econ NileCAM21
- Tier4 C1 (ISX021)
- Tier4 C2 (IMX490)

NGX018 (Hadron GMSL)

- USB 3.0 Support
- USB OTG Support
- GbE Phy Support
- NVMe Card Support
- Wifi/Bluetooth support
- CAN Support
- UART Support
- I2C Support
- GPIO Support
- PWM Support
- GMSL Camera Support

Supported GMSL Cameras:

- Leopard IMX390
- Leopard OWL

NGX020 (Boson for Orin)

• USB 3.0 Support



- USB OTG Support
- Display(HDMI)
- GbE Phy Support
- CAN Support
- UART Support
- SPI Support
- I2C Support
- PWM Support
- Wifi/Bluetooth Support
- NVMe Card Support
- Framos Camera Support

Supported Framos Cameras:

- FSM-IMX290
- FSM-IMX296
- FSM-IMX412
- FSM-IMX415
- FSM-IMX464
- FSM-IMX565
- FSM-IMX568
- FSM-IMX585
- FSM-IMX678

NGX021 (Boson22 for Orin)

- USB 3.0 Support
- USB OTG Support
- Display(HDMI)
- GbE Phy Support
- CAN Support
- UART Support
- SPI Support
- I2C Support
- PWM Support
- Wifi/Bluetooth Support
- NVMe Card Support
- 22-pin CSI camera connector Support

(No Camera Configs in Current BSP)

NGX022 (Lepton FPDLink III)

- USB 3.0 Support
- USB OTG Support
- Display(HDMI)



- GbE Phy Support
- CAN Support
- UART Support
- SPI Support
- I2C Support
- PWM Support
- Wifi/Bluetooth Support
- NVMe Card Support
- FPDLINK III Camera Support
- External Trigger Support

Supported Cameras:

• Econ NeduCAM25

3.2 Limitations and Known Issues

1. Micro SD card on CTI Xavier[™] NX carriers will not work with Orin[™] NX or Orin[™] Nano As pin mapping for those pins has changed.

2. Camera Port 4 on the Boson Carrier designed for Xavier[™] NX (NGX007) will not work with Orin[™] NX or Orin[™] Nano as they do not support CSI_4. Therefore only 2 camera 4-lane and 3 camera 2-lane configurations are provided.

A new carrier design "Boson for Orin (NGX020)" reroutes the csi lanes to stream on 4 ports. 4 camera 2-lane and 2 camera 4-lane configurations for the NGX020.

4. Installation

4.1 Obtaining NVIDIA® Jetpack

Before Installing the BSP you will need to install JetPack 5.1.2 on the host system using NVIDIA[®] SDK Manager (section 4.1.1) or from the NVIDIA[®] Embedded Download Center (section 4.1.2)

4.1.1 Installing JetPack from SDK Manager

For installing using sdkmanager, please follow installation steps from kdb373 for Jetpack 4.2+ https://connecttech.com/resource-center/kdb373/



4.1.2 Installing JetPack from NVIDIA® Embedded Download Center

1. Create a new directory for installing the Jetpack. Referred to as <BSP_ROOT> in these instructions.

2. Go to Jetpack Release Page https://developer.nvidia.com/embedded/jetson-linux-r3541

3. Download the "L4T Driver Package (BSP)" and "Sample Root Filesystem" files for Orin modules (t234 platform).

4. Put the "L4T Driver Package (BSP)" and "Sample Root Filesystem" in <BSP_ROOT>. Afterwards, you should have the following files in <BSP_ROOT>

- jetson_linux_r35.4.1_aarch64.tbz2
- tegra_linux_sample-root-filesystem_r35.4.1_aarch64.tbz2

5. Extract the "L4T Driver Package" tarball:

cd <BSP_ROOT> sudo tar -jxf jetson_linux_r35.4.1_aarch64.tbz2

6. You should now have a new directory called Linux_for_Tegra in your <BSP_ROOT> folder. Extract the "Sample Root Filesystem" into Linux_for_Tegra/rootfs.

sudo tar -C Linux_for_Tegra/rootfs/ -xjf tegra_linux_sample-rootfilesystem_r35.4.1_aarch64.tbz2

4.2 CTI BSP Installation

1. Copy the CTI-L4T-ORIN-NX-NANO-35.4.1-V###.tgz package into <BSP_ROOT>/Linux_for_Tegra.

If you are using Nvidia's SDK manager then "<BSP_ROOT>" will be: ~/nvidia/nvidia_sdk/<JetPack_Version>_Linux_JETSON_NX_ORIN_TARGETS/ or

~/nvidia/nvidia_sdk/<JetPack_Version>_Linux_JETSON_NANO_ORIN_TARGETS/ depending on your target module.

Otherwise if manually installing from the NVIDIA[®] Embedded Download Center <BSP_ROOT> will be the folder created previously

cp CTI-L4T-ORIN-NX-NANO-35.4.1-V###.tgz <BSP_ROOT>/Linux_for_Tegra

2. Extract the BSP: tar -xzf CTI-L4T-ORIN-NX-NANO-35.4.1-V###.tgz cd <BSP_ROOT>/Linux_for_Tegra



sudo tar -xzf CTI-L4T-ORIN-NX-NANO-35.4.1-V###.tgz

3. Change into the CTI-L4T directory: cd <BSP_ROOT>/Linux_for_Tegra/CTI-L4T

4. Run the install script (as root or sudo) to automatically install the BSP files to the correct locations:

sudo ./install.sh
#return to Linux_for_Tegra
cd ..

5. The CTI-L4T BSP is now installed on the host system and it should now be able to flash the Orin[™] NX/Orin[™] Nano module.

5. Flashing Orin[™] NX/Orin[™] Nano Modules

1. Connect an NVMe m.2 card to one of the m.2 slots on your Orin[™] NX/Orin[™] Nano carrier.

2. Connect the Orin[™] NX/Orin[™] Nano and Carrier to the computer via USB, following the instructions in the appropriate manual.

3. Put the system to be flashed into recovery mode, following the instructions in the appropriate manual

4. There are two options for flashing Jetson modules:

Using CTI's automated script: ./cti-flash.sh

Follow the menu and select your desired configuration. Once selected,

the device will start to flash.

Using the Manual Method with cti-nvme-flash:

Note do not add the ".conf" file extension to the <config> parameter:

Manual Flash: ./cti-nvme-flash.sh cti/<module>/<boardname>/<config>

<module> is either orin-nx or orin-nano depending on your module.



Examples: ./cti-nvme-flash.sh cti/orin-nx/boson/base ./cti-nvme-flash.sh cti/orin-nano/boson/base

5. Once the flashing has completed, the Orin[™] NX/Orin[™] Nano will reboot

6. Upgrading to a New Package Release

Upgrading L4T or CTI-BSP versions without reflashing is not currently supported.

7. Switching Profiles on Orin™ NX/Orin™ Nano

1. Open a terminal on the Orin[™] NX/Orin[™] Nano

- 2. Run "sudo cti-orin-nx-nano-fdt.sh"
- 3. Select the profile you wish to switch to from the menu.
- 4. Select the target module (Orin-NX or Orin-NANO) from the menu.
- 5. Restart the system

Note: This script updates the dtb by appending/replacing the FDT variable in extlinux.conf

8. Tier4 Camera Info

8.1 Tier4 C1

cti-tier4-firmware.sh is bundled with the rootfs and can be run directly from the linux shell from any location. This script is required for packing the firmware of C1 into the initrd filesystem. Failing to do so will cause the camera probe to fail.

To pack the firmware into the initrd filesystem, run the following command: cti-tier4-firmware.sh /boot/initrd tier4-isx021.bin. When the script is done, reboot the system for the changes to take effect.



8.2 Tier4 C2

Note that the Following trigger modes have been verified for Orin-NX/Orin-NANO:

ModeIndexMASTER_MODE_10FPS0MASTER_MODE_20FPS2MASTER_MODE_30FPS4

Manual triggering in a slave mode has currently not been verified.

The default is set as MASTER_MODE_30FPS, but you can set the trigger mode at runtime through the filesystem:

echo <n> > /sys/module/tier4_imx490/parameters/trigger_mode where n is the Index shown in the table above.

For 20FPS/30FPS on the C2:

When launching two cameras on the same deserializer at the same time using gstreamer, one of the camera streams intermittenly would freeze on first launch after boot. Relaunching would fix the stream, but staggering the launch of the cameras seemed to prevent this issue from happening. We tested with a 1 second delay, but it is likely you can use a shorter delay. This seemed to be an issue unique to Orin™ NX/Orin™ Nano This issue was not observed on the 10FPS master mode.

9. Change Log

Version ORIN-NX-NANO-35.4.1 V008, April 17, 2024

- Added support for Tier4 C1 (ISX021) and C2 (IMX490) to Polaris.
- Added support for LI OWL on Hadron GMSL

Version ORIN-NX-NANO-35.4.1 V007, April 12, 2024

- Added Framos IMX678 to Hadron.
- Added ArduCAM IMX477 to Photon and Hadron.
- Initial Release of Lepton (NGX022) with NeduCAM25 config.

Version ORIN-NX-NANO-35.4.1 V006, Feb 16, 2024

• Added Framos IMX585 to Boson and Boson for Orin.

Version ORIN-NX-NANO-35.4.1 V005, Feb 12, 2024

• Added Boson22 for Orin support for Orin[™] NX and Orin[™] Nano

Version ORIN-NX-NANO-35.4.1 V004, Feb 02, 2024



- BSP for Hadron GMSL NGX018 Rev A for Orin[™] NX and Orin[™] Nano
- Includes LI-IMX390 camera config.
- Added support for Econ E-CAM80 on Photon

Version ORIN-NX-NANO-35.4.1 V003, Dec 21, 2023

• Added support for Framos IMX568 to Boson and Boson for Orin.

Version ORIN-NX-NANO-35.4.1 V002, Dec 11, 2023

• Initial release of Polaris (NGX015) in mainline bsp. Includes configuration for Econ NileCAM21.

Version ORIN-NX-NANO-35.4.1 V001, Oct 12, 2023

- Initial release of Jetpack 5.1.2 (l4t 35.4.1) for Orin[™] NX/Orin[™] Nano
- Initial release of Boson for Orin (NGX020) which includes all of the Framos camera configs currently supported by the older boson carrier (NGX007).

Contact Connect Tech

If you have any problems, questions or suggestions regarding the Board Support Package and hardware, please feel free to contact Connect Tech Inc.

Contact Information		
Support	Please go to the installation guid	e <u>Connect Tech Resource Center</u> for product manuals, des, device drivers, BSPs and technical tips.
	Submit your <u>technical support</u> questions to our support engineers. Technical Support representatives are available Monday through Friday, from 8:30 a.m. to 5:00 p.m. Eastern Standard Time.	
Contact Information	support@connecttech.com sales@connecttech.com www.connecttech.com	
	Toll Free: Telephone: Facsimile:	800-426-8979 (North America only) +1-519-836-1291 519-836-4878 (on-line 24 hours)