

BOARD SUPPORT PACKAGE

For Connect Tech NVIDIA Jetson Xavier NX Carriers

BSP Version: Xavier-NX-32.5 V007

Last Updated: 2021/06/17

Introduction

This Board Support Package adds support for Connect Tech Jetson Xavier-NX family of carrier boards to Linux4Tegra. It includes any extra files required to use all the features of the carriers. Please check the "Product Specific Details" section for what features for your board is supported with this BSP release and the "Changes" section for the changes made between versions. You can check which version of the BSP you have installed by running: cat /etc/cti/CTI-L4T.version

Check for the Latest Version of the CTI-L4T BSP at: https://connecttech.com/resource-center/l4t-board-support-packages/

Requirements

- x86 based host machine running Ubuntu 16.04 or Ubuntu 18.04
- Jetpack 4.5 installed via NVIDIA SDK Manager (from NVIDIA Embedded Download Center)
- Xavier-NX module
- Connect Tech Xavier-NX Family Carrier
- USB Cable for flashing

*L4T version can be found in /etc/nv_tegra_release and will look like this: # R32 (release), REVISION: 5.0

Supported Cameras in BSP

ECON: NileCAM30: AR0330
ECON: STURDeCAM20: AR0230
ECON: e-CAM50_CUNX: AR0521
Leopard: LI-IMX390-GMSL2

• Arducam: IMX477

• Raspberry Pi Camera Module v2: IMX219

Basler*: daA2500-60mci**Basler*: daA4200-30mci

*NOTE: The pylon Camera Software Suite, which contains Basler's camera APIs and camera viewing application, is not included and must be installed separately. See "Installing Pylon SDK (For Basler)" below. **NOTE: The daA2500-60mci and daA2500-60mc are different camera models, check to make sure yours has an "i" at the end.



Installation (Preferred approach)

- Before Installing the BSP you will need to install JetPack 4.5 on the x86 host system using the NVIDIA SDK Manager or from the source packages on NVIDIA's website as detailed below.
- Copy the CTI-L4T-XAVIER-NX-32.5-V007.tgz package into ~/nvidia/nvidia_sdk/JetPack_4.5_Linux_JETSON_XAVIER_NX_DEVKIT/Linux_for_Tegra/
- Extract the BSP: tar -xzf CTI-L4T-XAVIER-NX-32.5-V007.tgz
- Change into the CTI-L4T directory: cd ./CTI-L4T
- Run the install script (as root or sudo) to automatically install the BSP files to the correct locations:

sudo ./install.sh cd ..

- The CTI-L4T BSP is now installed on the host system and it should now be able to flash the Xavier-NX.
- To flash on the Xavier-NX use the following (do not add ".conf"):

CTI Assisted Flashing: ./cti-flash.sh

Manual Flash: ./flash.sh cti/xavier-nx/photon mmcblk0p1

Installing JetPack from NVIDIA's Source packages (Alternate approach)

- Go to https://developer.nvidia.com/embedded/linux-tegra and download the "L4T Driver Package (BSP)" and "Sample Root Filesystem" files for Xavier NX. Alternatively, you can use the files "Tegra186_Linux_R32.5.0_aarch64.tbz2" and "Tegra_Linux_Sample-Root-Filesystem_R32.5.0_aarch64.tbz2" from your SDKManager downloads folder (This would be the folder you selected as the "Download folder" in step 2 "Details and License" of SDKManager).
- Create a directory named ~/nvidia/nvidia_sdk/JetPack_4.5_Linux_JETSON_XAVIER_NX_DEVKIT/ and copy the "Tegra186_Linux_R32.4.4_aarch64.tbz2" file you downloaded into that directory.
- Unzip the tarball with "sudo tar jxf Tegra186_Linux_R32.5.0_aarch64.tbz2". You should now have a new directory called Linux_for_Tegra in your folder. Change directories into that and then copy the "Tegra_Linux_Sample-Root-Filesystem_R32.5.0_aarch64.tbz2" file you downloaded into the rootfs folder.
- Change into the rootfs folder and unzip the tarball with "sudo tar jxf Tegra_Linux_Sample-Root-Filesystem_R32.5.0_aarch64.tbz2"



• You can change directories back to ~/nvidia/nvidia_sdk/JetPack_4.5_Linux_JETSON_XAVIER_NX_DEVKIT/Linux_for_Tegra/ and run "sudo ./appy_binaries.sh" if you wish to flash one of NVIDIA's devkits, or move on to installing CTI's BSP with the instructions above.

Flashing Xavier-NX

- Connect the Xavier-NX and Carrier to the computer via USB Following the instructions in the appropriate manual
- Put the system to be flashed into recovery mode, following the instructions in the appropriate manual
- Run ./flash.sh "./cti-flash.sh" or "./flash.sh cti/xavier-nx/<board> mmcblk0p1"mmcblk0p1 from Linux for Tegra directory
- Once the flashing has completed, the Xavier-NX will reboot
- To switch between different boards, you can repeat these steps. Alternatively follow the instructions below for runtime switching profiles on the Xavier-NX

Switching Profiles on Xavier-NX

- Open a terminal on the Xavier-NX
- Run "sudo cti-nx-fdt.sh"
- Select the profile you wish to switch to from the menu
- Restart the system

Note: This script updates dtb by appending/replacing the FDT variable in extlinux.conf. It also sets root=/dev/mmcblk0p1 by modifying the "APPEND" variable.

Installing Pylon SDK (For Basler)

Camera application development support for Basler camera models is provided by the "pylon Camera Software Suite" created by Basler. It can be downloaded from their website at: https://www.baslerweb.com/en/sales-support/downloads/software-downloads/#type=pylonsoftware;language=all;version=all;os=linuxarm;series=all;model=all

On your NX module, navigate to the webpage above and download the latest version of the pylon Camera Software Suite which is followed by "Linux ARM 64 bit - Debian Installer Package" (e.g. "pylon 6.2.0 Camera Software Suite Linux ARM 64 bit - Debian Installer Package"). After the download is complete, navigate to your Downloads directory over command line and run:

sudo dpkg -i pylon_<VERSION>_arm64.deb

replacing <VERSION> with the version number of the package. This will install Basler's camera SDK and documentation to the /opt/pylon directory.



If you wish to develop in Python, you will need to install an additional API with the following commands: sudo apt install python3-pip

sudo pip3 install https://github.com/basler/pypylon/releases/download/1.6.0/pypylon-1.6.0-cp36-cp36m-linux_aarch64.whl

To use the pylon viewer application, enter:

/opt/pylon/bin/pylonviewer

over the command line. For additional documentation about the pylon viewer application, please consult: https://docs.baslerweb.com/overview-of-the-pylon-viewer

For further support with camera application development with Basler product cameras, please consult Basler support at https://www.baslerweb.com/en/sales-support/support-contact/

Product Specific Details

NGX003 (Photon)

- USB 3.0 Support
- USB OTG Support
- MIPI Camera Support
- HDMI Support
- Micro SD Card Support
- NVMe Card Support
- PoE Support
- Wifi/Bluetooth Card Support
- Cellular Card Support
- RGB LED Support
- UART Support
- I2C Support
- GPIO Support

NGX004 (Quark)

- USB 3.0 Support
- USB OTG Support
- MIPI Camera Support
- Micro SD Card
- GbE Phy Support
- CAN Support
- UART Support
- I2C Support
- GPIO Support
- SPI Support
- PWM Support



NGX006 (Rudi-NX)

- USB 3.0 Support
- USB OTG Support
- GMSL Camera Support (ECON and Leopard Imaging)
- HDMI Support
- SD Card Support
- NVMe Card Support
- CAN Support
- GbE Phy Support
- Cellular Card Support
- Wifi/Bluetooth card Support
- UART Support
- RS485 Support
- I2C Support
- GPIO Support
- SPI Support
- PWM Support

Changes

Version Xavier-NX-32.5 V007, June 17, 2021

• Adding support for Basler Dart BCON for MIPI cameras

Version Xavier-NX-32.5 V006, May 07, 2021

• Restoring support for LI IMX390 GMSL cameras

Version Xavier-NX-FRAMOS-32.5 V005, April 23, 2021

- Added support for Framos IMX464 camera sensor
- NOTE: Only IMX464 and IMX415 are supported on this BSP release. No other cameras supported

Version Xavier-NX-32.5 V004, April 23, 2021

Added support for ECON STURDeCAM20: AR0230 cameras for Rudi-NX

Version Xavier-NX-FRAMOS-32.5 V003, April 01, 2021

- Adding support for FRAMOS IMX415 camera for Boson carrier
- NOTE: No other cameras are supported on this BSP release

Version Xavier-NX-AVT-32.5 V002, March 05, 2021

- Adding support for Allied vision cameras for Photon and Quark
- NOTE: No other cameras are supported on this BSP release

Version Xavier-NX-32.5 V001, February 08, 2021

- Initial Release for L4T 32.5
- IMX390 not supported in this release
- Bootloader OTA upgrades supported



• OTA source list does not include previous releases as they are from a different major revision

Version Xavier-NX-32.4.4 V005, January 11, 2021

- Added support for Arducam 12.3MP IMX477 HQ Camera Module for quark.
- Booting Off External media: NVME supported.

Version Xavier-NX-32.4.4 V004, December 17, 2020

- Added support for Arducam 12.3MP IMX477 HQ Camera Module for Photon.
- Booting Off External Media like SD card and NVME not supported.

Version Xavier-NX-32.4.4 V003, December 08, 2020

- Resolved disagrees about module layout issue for loading external kernel modules.
- Booting Off External Media like SD card and NVME not supported.

Version Xavier-NX-32.4.4 V002, December 03, 2020

- Added support for ECON e-CAM50-CUNX camera with AR0521 sensor on photon and quark.
- Booting Off External Media like SD card and NVME not supported.

Version Xavier-NX-32.4.4 V001, November 12, 2020

- Initial Release for L4T 32.4.4
- Booting Off External Media like SD card and NVME not supported.

Version Xavier-NX-32.4.3 V006, November 02, 2020

• Updated Readme file

Version Xavier-NX-32.4.3 V005, October 07, 2020

• Internal Release

Version Xavier-NX-32.4.3 V004, October 7, 2020

- Integrated Leopard patch IMX390 single camera on rudi-nx.
 - o A single imx390 camera can function when connected to 1 deserializer.
 - With 2 deserializers on rudi-nx, 2 cameras can also be connected(one on each deserializer) at a time.
 - o /dev/video0 and /dev/video1 are the video devices.
- Incorporated Leopard patch for IMX390 colour issue(for 4-CAM).
 - o This also supports single camera.
- Recommends to perform powercycle while switching camera profiles using extlinux.conf

Version Xavier-NX-32.4.3 V003, August 20, 2020

- Supports apt-get upgrade
- Upgrade support from cti debian server from this version onwards
- Image backup available in case to have bootoptions in extlinux.conf
- Installs a script to modify extlinux.conf to switch dtb
 - Script: cti-nx-fdt.shInstall path: /usr/bin
 - o Execute: sudo cti-nx-fdt.sh



• Note: This script updates dtb by appending/replacing FDT variable. It also sets root=/dev/mmcblk0p1 by modifying "APPEND" variable

Version Xavier-NX-32.4.3 V001, July 20, 2020

• Initial Release for L4T 32.4.3

Version Xavier-NX-32.4.2 V005, July 06, 2020

• Added PWM support for Rudi-NX and Quark

Version Xavier-NX-32.4.2 V004, June 29, 2020

- Added support for IMX390 and AR0330
- Added support for Quectel EM06 modem

Version Xavier-NX-32.4.2 V003, June 03, 2020

- Fixed issue with not being able to login when using SDK Manager
- Fixed an issue with nvpmodel not being configured correctly
- Rudi-NX carrier release

Version Xavier-NX-32.4.2 V001, May 07, 2020

• Initial Release for the Xavier-Nx

Contact Connect Tech

If you have any problems, questions or suggestions regarding the Board Support Package and hardware, please feel free to contact Connect Tech Inc.

Contact Information	
	Please go to the <u>Connect Tech Resource Center</u> for product manuals, installation guides, device drivers, BSPs and technical tips.
Support	Submit your <u>technical support</u> questions to our support engineers. Technical Support representatives are available Monday through Friday, from 8:30 a.m. to 5:00 p.m. Eastern Standard Time.
Contact Information	support@connecttech.com sales@connecttech.com www.connecttech.com
	Toll Free: 800-426-8979 (North America only) Telephone: +1-519-836-1291 Facsimile: 519-836-4878 (on-line 24 hours)