Connect Tech

BOARD SUPPORT PACKAGE

For Connect Tech NVIDIA® Jetson AGX Orin™ Carriers

BSP Version: ORIN-AGX-35.6.2 V002
Last Updated: 2026/07/07

1. Introduction

This Board Support Package adds support for the Connect Tech Jetson AGX Orin™ family of carrier boards to Linux4Tegra. It includes any extra files required to use all the features of Connect Tech carriers.

Please check Section 3 for supported features for your board and Section 8 for the changes made between versions. You can check which version of the BSP you have installed by running:

cat /etc/cti/CTI-L4T.version

Check for the Latest Version of the CTI-L4T BSP at:
https://connecttech.com/resource-center/l4t-board-support-packages/

2. Requirements

- x86/x64 based host machine running Ubuntu 18.04 or 20.04
- JetPack 5.1.5 / L4T 35.6.2 installed (see Section 4)
- AGX Orin™ module
- Connect Tech AGX Orin™ Carrier
- USB Cable for flashing

*L4T version can be found in /etc/nv_tegra_release and will look like this:
R35 (release), REVISION: 6.2

3. BSP Features

3.1 Supported Modules in BSP

- AGX Orin™ 32GB
- AGX Orin™ 64GB

- AGX Orin™ Industrial

3.2 Supported Cameras in BSP (All Carriers)

- Leopard IMX390
- FLIR Boson ADK
- ECON NILECAM82
- ECON NeduCAM25
- Stereolabs ZEDX stereocam
- Stereolabs ZEDOneGS
- Stereolabs ZEDOne4K

3.3 Product Specific Details

AGX201 (Forge)

- 10G and 1G ethernet Support.
- CAN Support.
- Display Port Support.
- USB 3.2 Support.
- USB OTG Support.
- I2C Support.
- SPI Support.
- UART Support.
- RS232/485 Support.
- GPIO Support.
- M.2 pcie Support.
- Key E 2230 Wifi/BT.
- Key B 3042/3052 LTE/5G with micro SIM.
- Micro SD support.
- JCB002 GMSL adapter support.
- JCB006 FPDLink III adapter support.

AGX202/AGX203 (Rogue-Orin/Rogue-RX)

- x2 10G ethernet Support.
- CAN Support.
- HDMI Support.
- USB 3.2 Support.
- USB OTG Support.
- I2C Support.
- SPI Support.
- UART Support.
- RS232/485 Support.
- GPIO Support.

- M.2 pcie Support.
- Key E 2230 Wifi/BT.
- Micro SD support.
- JCB002 GMSL adapter support.
- JCB006 FPDLink III adapter support.

ESG620 (Anvil)

- 10G and 1G ethernet Support.
- CAN Support.
- Display Port Support.
- USB 3.2 Support.
- USB OTG Support.
- I2C Support.
- SPI Support.
- UART Support.
- RS232/485 Support.
- GPIO Support.
- M.2 pcie Support.
- Key E 2230 Wifi/BT.
- Key B 3042/3052 LTE/5G with micro SIM.
- Micro SD support.
- Oculink support
- Endpoint Mode not Supported
- JCB002 GMSL adapter support.
- JCB006 FPDLink III adapter support.

3.3.1 Installing ZED X camera SDK

The ZED SDK is required to operate the ZED X camera. To use the SDK, Nvidia's CUDA, along with a few other dependancies, must first be installed (It is not installed automatically with this BSP).

To install these dependancies, run this command:
"sudo apt install zstd libqt5network5 libqt5opengl5 libqt5sql5 libqt5xml5 cuda"

The ZED SDK can then be downloaded onto the AGX Orin™ from the Stereolabs website here:
https://www.stereolabs.com/developers/release/

Click on "SDK Downloads", then the link for "ZED SDK for JetPack 5.1.2 (L4T 35.4)".
Note: ZED X drivers are already included in this BSP and do not need to be downloaded.

Once you have downloaded the executable onto your AGX Orin™ system, follow the rest of the instructions under "Download and Install the ZED SDK" at this link:
https://www.stereolabs.com/docs/installation/jetson/

Additional questions about the SDK and camera applications can be answered by

Stereolabs at https://support.stereolabs.com/hc/en-us/

3.3.2 ZED X camera SDK Compatibility

The maximum number of sensors that are currently supported for zedx and zedone camera configs is 8. Zedx stereo cameras have 2 sensors per camera and therefore the Zedx stereo cam config supports 4 stereo cameras (one per deserializer).

Due to a limitation with the number of i2c addresses that can be translated on the jcb002, the ZedONE4K only supports one full IMU per each deserializer. The IMU that is fully supported is PHY A when 2 cameras are connected to the same deserializer. When using one camera at a time on a deserializer the IMU will work fully whether the camera is on PHY A or B.

The address that could not be translated was the IMU gyroscope on PHY B. It is left at the default address of 0x68, the accelerometer on PHY B is still translated at 0x17 and is available for use when 2 cameras are connected to the same deserializer. Note that both IMUs gyroscopes respond at the default address, leading to invalid readings when both are connected to the same deserializer.

Note that for ZedONE4K you will be able to stream 2 cameras off the same deserializer using the ZED SDK, regardless of this address conflict.

The following diagram shows where SDIOA and SDIOB are for deserializers 1-4 on the JCB002's Quad Fakra connectors:

When using the Zedx stereo camera you can connect to either A or B but not both (per deserializer).

3.4 Limitations and Known Issues

1. Due to firmware and bootloader limitations there is no way to move a module flashed from one AGX Orin™ carrier to another without reflashing. This includes the NVIDIA® Devkit. This means a module flashed for the AGX Orin™ Devkit cannot be used with a CTI carrier without reflashing the module.

2. When using 2 ZedONE4K cameras off of one deserializer, only one full IMU will

work due to a lack of available i2c aliases on the serializer. The working camera will be on PHY A when two are connected, and either PHY when one camera is connected per deserializer.

4. Installation

4.1 Obtaining NVIDIA® Jetpack

Before Installing the BSP you will need to install JetPack 5.1.3 on the host system using NVIDIA® SDK Manager (section 4.1.1) or from the NVIDIA® Embedded Download Center (section 4.1.2)

4.1.1 Installing JetPack from SDK Manager

Please follow installation steps from kdb373 for Jetpack 4.2+
https://connecttech.com/resource-center/kdb373/

4.1.2 Installing JetPack from NVIDIA® Embedded Download Center

1. Create a new directory for installing the Jetpack. Referred to as <BSP_ROOT> in these instructions.

2. Go to Jetpack Release Page https://developer.nvidia.com/embedded/jetson-linux-r3562

3. Download the "L4T Driver Package (BSP)" and "Sample Root Filesystem" files for AGX Orin™

4. Put the "L4T Driver Package (BSP)" and "Sample Root Filesystem" in <BSP_ROOT>. Afterwards, you should have the following files in <BSP_ROOT>

- jetson_linux_r35.6.2_aarch64.tbz2
- tegra_linux_sample-root-filesystem_r35.6.2_aarch64.tbz2

5. Extract the "L4T Driver Package" tarball:

```
cd <BSP_ROOT>
sudo tar -jxf jetson_linux_r35.6.2_aarch64.tbz2
```

6. You should now have a new directory called Linux_for_Tegra in your <BSP_ROOT> folder. Extract the "Sample Root Filesystem" into Linux_for_Tegra/rootfs.

sudo tar -C Linux_for_Tegra/rootfs/ -xjf tegra_linux_sample-root-filesystem_r35.6.2_aarch64.tbz2

4.2 CTI BSP Installation

1. Copy the CTI-L4T-ORIN-AGX-35.6.2-V###.tgz package into <BSP_ROOT>/Linux_for_Tegra.

If you are using Nvidia's SDK manager then "<BSP_ROOT>" will be:
~/nvidia/nvidia_sdk/<JetPack_Version>_Linux_JETSON_AGX_ORIN_TARGETS/

Otherwise if manually installing from the NVIDIA® Embedded Download Center
<BSP_ROOT> will be the folder created previously

cp CTI-L4T-ORIN-AGX-35.6.2-V###.tgz <BSP_ROOT>/Linux_for_Tegra

2. Extract the BSP: tar -xzf CTI-L4T-ORIN-AGX-35.6.2-V###.tgz
cd <BSP_ROOT>/Linux_for_Tegra
sudo tar -xzf CTI-L4T-ORIN-AGX-35.6.2-V###.tgz

3. Change into the CTI-L4T directory:
cd <BSP_ROOT>/Linux_for_Tegra/CTI-L4T

4. Run the install script (as root or sudo) to automatically install the BSP files to the correct locations:

sudo ./install.sh
#return to Linux_for_Tegra
cd ..

5. The CTI-L4T BSP is now installed on the host system and it should now be able to flash the AGX Orin™ module.

5. Flashing AGX Orin™ Modules

1. Connect the AGX Orin™ and Carrier to the computer via USB, following the instructions in the appropriate manual.

2. Put the system to be flashed into recovery mode, following the instructions in the appropriate manual

3. There are two options for flashing Jetson modules:

Using CTI's automated script:

./cti-flash.sh

Follow the menu and select your desired configuration. Once selected,

the device will start to flash.

Using the Manual Method:

Note do not add the ".conf" file extension to the <config> parameter:

Manual Flash: ./flash.sh cti/<module>/<boardname>/<config> mmcblk0p1

<module> is orin-agx or orin-agxi (orin-agx industrial)

Example:
./flash.sh cti/orin-agx/forge/base mmcblk0p1
./flash.sh cti/orin-agxi/forge/base mmcblk0p1

4. Once the flashing has completed, the AGX Orin™ will reboot

6. Upgrading to a New Package Release

Upgrading L4T or CTI-BSP verisons without reflashing is not currently supported.

7. Switching Profiles on AGX Orin™

1. Open a terminal on the AGX Orin™

2. Run "sudo cti-orin-agx-fdt.sh"

3. Select the profile you wish to switch to from the menu

4. Restart the system

Note: This script updates the dtb by appending/replacing the FDT variable in extlinux.conf

8. Change Log

Version ORIN-AGX-35.6.2-V002 July 7, 2026

- Fixed an issue affecting USB3 devices after UEFI boot services exit.

Version ORIN-AGX-35.6.2-V001 Sept 16, 2025

- First release of l4t 35.6.2 (Jetpack 5.1.5) on AGX Orin™ and AGX Orin™ Industrial.

- Includes configurations for Stereolabs ZEDX, ZEDOneGS and ZEDOne4K.
- Includes configurations for Leopard IMX390, FLIR BOSON, Econ NeduCAM25 and Econ NileCAM82.

Contact Connect Tech

If you have any problems, questions or suggestions regarding the Board Support Package and hardware, please feel free to contact Connect Tech Inc.

Contact Information	
Support	Please go to the Connect Tech Resource Center for product manuals, installation guides, device drivers, BSPs and technical tips. Submit your technical support questions to our support engineers. Technical Support representatives are available Monday through Friday, from 8:30 a.m. to 5:00 p.m. Eastern Standard Time.
Contact Information	support@connecttech.com sales@connecttech.com www.connecttech.com Toll Free: 800-426-8979 (North America only) Telephone: +1-519-836-1291 Facsimile: 519-836-4878 (on-line 24 hours)